



LUND EQUIPMENT COMPANY, INC.

P.O. BOX 213
BATH, OHIO 44210
PHONE: 330/659-4800
330/659-3707
FAX: 330/659-9347

LOCK INSTALLATION INSTRUCTIONS

- 1.) If cabinet door is open – Remove large nut from lock cylinder and remove lock from lock hole. Insert new lock in hole and tighten large nut over lock cylinder.
- 2.) If keys are lost and door is locked – using 3/8” drill bit, drill 1 inch deep hole through keyhole in center of lock. Enlarge hole if needed. Locking cam should break off and door can be opened.

NOTE: LOCK CAM MAY HAVE TO BE BENT SLIGHTLY TO FALL FREELY BEHIND LOCK CHANNEL.